

**Dear 2005 and newer Honda Odyssey and Ridgeline Owners
2006 and newer Honda Civic, Accord and Pilot Owners
2007 and newer Honda Fit and CRV Owners**


One of the most convenient and important features on your vehicle is the technology of the Maintenance Minder System. The onboard computer judges your driving conditions and habits then calculates the remaining engine oil life, displaying it as a percentage. The Maintenance Minder System lets you know when scheduled maintenance items require service. **Oil Life should be at 15% before changing.**

MAINTENANCE ICON

Shows Maintenance Main Symbol (“alpha”) as well as Maintenance Sub-Symbols (“numeric”).



LX and EX editions



EXL and

Touring editions

A ◇	Replace engine oil.*
B	Replace engine oil* and filter. Service front and rear brakes. Rotate tires,** inspect for wear and adjust pressure. Inspect parking brake adjustments. Inspect tie rod ends, steering gear box and boots. Inspect suspension components. Inspect driveshaft boots. Inspect brake hoses and lines (including ABS). Check all fluid levels, condition of fluids and check for leaks. Inspect exhaust system. Inspect fuel lines and connections.

1 ◇	Rotate tires,** inspect for wear and adjust pressure.
2 ◇	Replace air cleaner element. Replace dust and pollen filter. Inspect and adjust drive belt.
3 ◇	Replace automatic transmission fluid. – use only Genuine Honda ATF-Z1.
4	Replace spark plugs. Replace timing belt, inspect water pump. Inspect valve clearance, cold engine.
5 ◇	Replace engine coolant. – use only Genuine Honda long life coolant.
6 ◇	Rear differential oil change

◇ **No Appointment Required** – Express Service Mon-Fri 7:30-5:00
Sat 8:00-3:00

*Use only Genuine Honda 5W-20 motor oil. **Tires may require more frequent rotation depending on road conditions, alignment and driving habits.

SPECIFIC ADDITIONAL REQUIRED MAINTENANCE

Every 24,000 km	Replace air cleaner element if vehicle is regularly driven in dusty conditions.
Every 24,000 km	Replace dust and pollen filter if vehicle is regularly driven in urban areas with high concentration of emissions from industry and diesel-powered vehicles.
48,000 km	Replace automatic transmission fluid and every 48,000 km thereafter if vehicle is regularly driven in mountainous areas at very low speeds – use only Genuine Honda ATF-Z1
100,000 km	Replace timing belt if vehicle is regularly driven in very low temperatures (under -29C; -20F).
Every 256,000 km	Inspect idle speed
Every 3 years	Replace brake fluid. – use only Genuine Honda brake fluid